



Features

- M Powerful shear force provides highly security.
- Compatible with double swing doors.
- Suitable for narrow door width installation.
- ☑ Optional SMB-001 brackets for surface mount installation.
- M Horizontal or vertical installation.
- M Anti-Residual magnetism designed.
- Power input 12~ 24 VDC (self-regulating).

Statement

GEM Shear Locks provide up to maximum shearing 2700 pounds force and fullv concealed flush mounting in aluminum, wood and steel doors, combine the best in failsafe performance with the most advanced features in shear lock design. Concealed lock mounting is an important feature, enhancing aesthetic appearance. Standard built-in field adjustable automatic relock switch with 1 to 6 second relock time delay.

The GS-705 series are available in two models, GS-705-30 and GS-705-35. can be fitted in either aluminum, wooden, steel or exit doors with the assistance of SMB-001 bracket. This manual gives a gudie to all of the above applications and other useful installation information

Specifications

- Operating Voltage: 12~24VDC
- Cuttent Draw:
 - GS-705-35:Pull in:1.9A . Holding: 0.55A/12VDC Pull in:1.2A, Holding: 0.35A/24VDC
 - GS-705-30:Pull in: 1.7A, Holding:0.5A/12VDC Pull in: 1.1A, Holding: 0.32A/24VDC

(at 20°C)

- Magnetic bond sensor monitor output (SPDT rated 1A/30VDC), indicates the door locked or unlocked.
- Locking time delay: 1~6 seconds adjustable
- Operating Temperature: -30°C~+55°C
- Humidity: 0~95% non-condensing.
- Shear force as 2,200lbs ~Max. 2,700lbs.
- Special Finishe for magnet and armature plate: Zinc plated
- Epoxy Potting Compound: E87252(S), UL94V-0
- Door Gap (Between the lock and armature plate): 3mm (1/8") maximum.
- Net Weight: GS-705-35: 2.2Kg , GS-705-30: 1.8Kg



Anti-Residual Magnetism design

Our electromagnet locks feature Anti-Residual Magnetism (ARM) which ensures the door can be opened without anyresistance from left over magnetism imparted to the armature plate.

Patent:

113640 ZL96-2-15062.2



Application

Horizontal Installation









Optional Bracket

The GS-705-35 may also be fitted semi-flush or sureface installation with the use of the SMB-001 brackets . The magnet should be fitted to the door transom and the housing holding the armature on to the door. It is vital that a minimum gap of 3mm exists between the magnet and the armature, to allow correct operation.



Semi-Flush Installation





Surface Installation





Warranty

The product is warranted against defects in material and workmanship while used in normal service for a period of 5 years from the date of sale to the original customer. The GEM policy is one of continual development and improvement; therefore GEM reserves the right to change specifications without notice.

GS-705 Shear Lock Installation Instruction

Important Notes

Install the magnet assembly into the door frame before installation the armature assembly into the door leaf. The magnet assembly requires space to run wires, as wall as space for the recesses portion of the unit. However, make sure that the position selected for the magnet assembly leaves enough room on the door to install the armature assembly.

Unbalanced air conditioning (stack pressure) can hinder door alignment and must be corrected to help insure positive locking. It is important to note that the Shear Locks need a regulated 12VDC (or 24VDC) at the lock, and use the highest guality door closer only. Positive centering door closers are required for all double acting door applicators to help attain consistent dead center alignment. Also the door latching problems must be corrected prior to installation.

Specifications

Holding Force	2,200lbs~Max. 2,700lbs	
Power Input	12~24VDC (self-regulating)	Fixing Lu
GS-705-35 Current Draw GS-705-30 Current Draw	Pull in: 1.85A, Holding: 0.45AMP/12VDC Pull in: 1.1A, Holding: 0.25AMP/24VDC Pull in: 1.8A, Holding: 0.45AMP/12VDC Pull in: 1.1A, Holding: 0.25AMP/24VDC (At temperature 20°C)	Bulge Lu
	NOTE: The unit does not require initial voltage increase to operate.	Magne
Finish	Magnet and Armature: Zinc plated, Housing: Black powder coated	Tapping scree
Monitoring Output	Magnet bond sensor output, SPDT rating 1AMP/30VDC dry contact	Armatur B
Door Gap	3mm (1/8") maximum	
Operating Temp	-30°C to +50°C	
Auto Relocking timer	1~6 seconds adjustable (Default: 3 sec)	

Connecting Diagram



Caution:

Make sure that the "+" and "-" wire are connected correctly. Failure to observe polarity will result in a short circuit and is not covered by products warrant.

Dimensions





Flush Installation







Bulge Lugs is used when fixing screws cannot fix Fixing Lugs on the door frame due to the shallow door frame. When the situation happens, use the Bulge Lugs to increase the thickness of the frame.



Flat Lugs is used when the door frame is deep, and to prevent the Electromagnetic Lock or the Armature Plate caved in, add flat lugs to raise the plane (level) of the Electromagnetic Lock face or the Armature Plate face to the door frame surface.

1. Make sure the gap between the door top rail and frame header is within 3mm. adjust the gap as required.

Adjust single acting door and door closer to insure the 2 door settles immediately and is fully closed . (Adjust double acting door and POSITIVE CENTERING DOOR CLOSER to insure the door settles immediately and is fully closed and rest in the dead center of the frame.)

3 Locate the vertical centerline of the magnet and armature as possible to the leading door edge.

Determine the horizontal centerline of the door top rail 4. thickness. The Armature centerline will be the same. Mark the door per template.

Before determining the frame header centerline single 5. acting door must be fully closed. Double acting doors must be fully closed and rest in the dead center of the frame. Mark the frame header per the template. Prepare the door and frame per the template.

6. When installing GS-705, mark the timer adjustment as required and test the locking time delay prior to mounting in the frame. The locking time delay is field adjustable for 1~6 seconds and is factory set at approximately 3 seconds.

7 Install the Shear lock and armature with the auto relock switch assembly towards the leading edge of the door. For proper operation the armature must be adjusted upward as close as possible and parallel to the Shear Lock without interfering with opening and closing of the door. Proper operation cannot be expected with more than 3 mm gap between the armature and the magnet. Use the key wrench provided to adjust the armature vertical adjustment screws.

8 With the door closed turn the lock power on, check the lateral alignment. The armature locking bolt should be centered to magnet keep hole. Adjust the locking time delay(GS-705) to avoid early activation and help insure positive locking on door closure. Adjust inward to delay Shear Lock activation. Don't adjust higher than the armature rest position.

9 Repeat steps 7,8 as necessary following shear lock replacement. Cycle the door and Shear Lock several times after the completion of the installation.

_	
The Maximum Gap between the Lock and Armature plate is 3 mm	
ing supplied key wrer just armature plate to app	hey wrench och to

Us ad mm of gap between magnet and armature.

SMB-001 Bracket For **GS-705-35** Surface mount installation Identify the insufficient thickness / width of the door leaf or frame header and inspect to determine if SMB-001 bracket is required.



Unit: mm

Semi-Surface Installation

The **GS-705-35** may also be fitted semi-surface with the use of the SMB-001 Bracket. The magnet should be fitted to the door transom and the housing holding the armature on to the door. It is vital that a maximum gap of 3mm exists between the magnet and the armature, to allow correct operation.





Using supplied key wrench to adjust armature plate to approx. 3 mm of gap between magnet and armature.

Surface Installation

The **GS-705-35** may also be fitted surface mounted using 2pcs of the SMB-001 Bracket. The housing holding the magnet should be fitted above the door and the housing holding the armature on to the door. It is vital that a maximum gap of 3mm exists between the magnet and the armature, to allow correct operation.





Using supplied key wrench to adjust armature plate to approx. 3 mm of gap between magnet and armeture.

Blind Nut Installation

-





Insert two Blind Nuts into separate holes, one for each fixing screw.



Use the allen wrench. To slowly tighten the Blind Nut. (Don't turning over)



This compress the Blind Nut so that it remains permanently fixed in the frame.



Remove the tool.

M6 Scr ew Blind Nut

Use M6 Screws fixing SMB-001brackets.

Problems	Possible Cause	Solution				
	The gap between the Armature Plate and the Shear Lock is exceeding 3mm.	Adjust the Armature Plate and arrange the gap between the Armature Plate and the Shear lock within 3mm.				
Door does not lock	No power.	Electrically Checked with an Ammeter, it must be powered with the correct input voltage and checked to see if it draws the specified current.				
	The door leaf does not return back at the correct position.	Positive centering door closers are required for all double acting door applicators to help attain consistent dead center alignment.				
	The gap between the Armature Plate and the Shear Lock is exceeding 3mm.	Adjust the Armature Plate and arrange the gap between the Armature Plate and the Shear lock within 3mm.				
The Armature Plate keep repeating the magnetic	Voltage and / or current is too low.	Electrically Checked with an Ammeter, it must be powered with the correct input voltage and checked to see if it draws the specified current.				
	The gap between the Armature Plate and the Shear Lock is unequal.	Adjust the Armature Plate and make sure the gap between the Armature Plate and the Shear Lock is equal.				
	The locking bolt does not correctly seat inside the keep hole of the Shear Lock.	Adjust the locking bolt of the Armature Plate and make sure it correctly seats inside the keep hole of the Shear Lock.				
The Armature Plate is not at the	The position of the locking bolt is not correct.	Adjust the locking bolt of the Armature Plate and make sure it correctly seats inside the keep hole of the Shear Lock.				
right position and the locking bolt cannot seat correctly into the keep hole of the Shear	The gap between the Armature Plate and the Shear Lock is unequal.	Adjust the Armature Plate and make sure the gap between the Armature Plate and the Shear Lock is equal.				
LOCK.	The setting of 'Auto Relocking time delay' is too short.	Adjust the setting of 'Locking time delay to appropriate.				



Use spanner and allen wrench to release the Locking Bolt on the Armature Plate. Rotate the position of the Locking Bolt in order to correctly seat inside the keep hole of the Shear Lock.



Make sure the gap between the Shear Lock and the Armature Plate are the same while adjusting the gap.



Since the current draw, which operates the Shear Lock, is large (1.8A/12VDC; 1A/24VDC), it is necessary to make sure the condition of the wire is capable for long distance usage. It is also necessary to make sure the output current of the Shear Lock is sufficient for the power that the manufacturer listed.

Distance in feet from power source to farthest locking device													
Minimum Wire Gauge for 12 VDC	AMPS 0.25 0.50 0.75 1.00 1.50 2.00	25f 18 18 18 18 18 18 18	50f 18 18 18 16 14 14	75f 18 18 16 14 12 12	100f 18 16 14 14 12	150f 18 16 12 12	200f 16 14 12	250f 16 12	300f 14	400f 14	500f 12	1000f	6
Minimum Wire Gauge for 24 VDC	AMPS 0.25 0.50 0.75 1.00 1.50 2.00	25f 18 18 18 18 18 18 18	50f 18 18 18 18 18 18 18	75f 18 18 18 16 16 14	100f 18 18 18 16 14 14	150f 18 18 16 14 14 14	200f 18 16 14 14 12	250f 18 16 14 12	300f 18 14 12 12	400f 16 14 12	500f 16 12	1000f 16	