

AC8000 ACCESS CONTROL SYSTEM

PC Access Control System for single, double or multi door installations via LAN or WAN connection providing Time Attendance and Access Control Monitoring Solutions

Easy setup within 15 minutes

Windows Server, Windows 7, XP, Windows Vista, Windows 8 & Windows 10 compatible as well as SQL



AC8000 Access Control System

Single door to multi door controlled

LAN and/or WAN connection

Plug 'n' Play directly in to a laptop, desktop or tablet

Windows Based

Instant adding/deletion of users

20,000 users

100,000 offline transactions

Multiple Reports to Excel

Multiple Users

Password Management

Access monitoring (Entry/exit)

Time & Attendance

Timed Profiles

Timed Door Open

Real Time Monitoring

Fire Alarm Input

Keypad Operation

Master PIN Code

Instant Lock Out

Anti-Tail Gate

And much more.....


Index

Connection & Drawings	Pages 2 - 5
Login & main software interface layout	Page 6
Changing login password & Software registration	Page 7
Add controllers	
Basic (Without hub or router required), LAN or WAN connection	Pages 8 – 10
Access Control	
Check/test controller communication	Page 11
Edit/rename doors & lock status	Page 12
Adding users and/or departments	Pages 13 – 15
Creating access privileges for users	Pages 16 – 17
Editing access privileges for users	Page 18
Amending lost cards/fobs	Page 19
Query card/fob user records	Page 20
Monitoring user access & location of users	Pages 21 – 26
Database backup & restore	Page 27
Extended functions (Password required)	Pages 28 – 30
Time profiles for users, departments & doors	Pages 31 – 33
Peripheral configuration (Fire alarm interface & regulations)	Pages 34 - 42
Keypad operation	Pages 43 - 46
Anti-passback	Page 47
Interlock	Page 48
Task list (Automatic door control opening)	Pages 49 - 50
Attendance (Time & Attendance & reports)	Pages 51 - 57
Meal setup	Pages 58 - 62
SQL Server setup	Page 63 - 64

Typical Layout Drawing


Two options for connection, either directly to a PC or via a router

For illustration purposes, the yellow wire for the door reader /s is white




AC8001 (One) Door Controller

For illustration purposes, the yellow wire for the door reader/s is white



AC8002 (Two) Door Controller


For illustration purposes, the yellow wire for the door reader/s is white



AC8001/2 Door Controller

Standard connection of a fire alarm input (AC-FAB – Optional Fire Alarm Board)

For illustration purposes, the yellow wire for the door reader/s is white




Login

When you first activate the software, it will ask you for a **User Name** and **Password**, by default the user name is **"abc"** and the password is **"123"** (without speech marks)



Once the user name and password have been entered correctly, you will be displayed with the main interface screen. At the top left hand side you will see the three main **"Getting Started"** buttons to set you up and running in less than 15 minutes. This particular interface can be hidden or deactivated at any time by clicking **Tools / Auto Login**

A majority of the main buttons also have short cuts to their relevant features by right clicking your mouse button




Change Password


Tools/Edit Operator

If you wish to change the user name and password, click **Tools/Edit Operator**

You can also bypass the manual login procedure by clicking **Tools/Auto Login**



A dialog box titled "Operator--abc" with a close button (X) in the top right corner. It contains three text input fields: "Name:" with the value "abc", "New Password:", and "Confirmed Password:". At the bottom, there are two buttons: "OK" and "Cancel".



A dialog box titled "Option" with a close button (X) in the top right corner. It has three tabs: "Language", "Interface Title", and "Auto Login". The "Auto Login" tab is selected, showing a checked checkbox labeled "Auto Login". At the bottom, there are two buttons: "OK" and "Cancel".


Forgotten user name and password

In the event that you cannot remember your user name and password to login in to the software, please contact your supplier who will give you full instructions as to what is required. It may take up to 24hrs to reset your software and a charge may be incurred for this service


Software Registration

Help/About

The software provides a timed evaluation period of approximately three months before it expires, in order to continue the full use, please ensure you register the software. Enter the relevant details and registration code which can be obtained from your supplier



An "About" dialog box showing software information. The text includes: "AC8000 Access Control System", "Software Version: 7.55.81.40529", "Database Version: 81 [Microsoft Access]", and ".Net Framework 2.0.50727.5477". At the bottom, it says "Suggest: 1024*768 or above" and has two buttons: "Register" and "Close".



A "Register" dialog box with three text input fields: "Company Name:", "Building Company:", and "Register Code:". At the bottom, there are two buttons: "OK" and "Exit".

Add Controller/s – LAN or WAN Connection


LAN Connection – Local Area Network via hub, router or directly to a PC or laptop

In order to add the access controller/s to the software, simply Click **Add Controller By Searching** located on the top left hand side. The software will then locate the controller and provide the required details for you automatically. This procedure is also required if/when adding additional controllers

You will then be displayed with this screen confirming the controller information. Click **Add Found To Database** followed by **Close** to confirm

Click **Configure** if you require *WAN Connection*


Port Forwarding is required to be setup for *WAN Connection* via your hub or router



LAN Connection (Local Area Network)

Revert to the main screen and click **Configuration/Controllers/Edit** and choose Small Network for LAN communication or Medium/Large Network if you require to control the system via Internet communication


Click **Next** and you can edit the door names and control status of the doors. When complete, press **OK**



WAN Connection (Wide Area Connection)

Revert to the main screen and click **Configuration/Controllers/Edit** and choose Medium/Large Network for WAN communication via Internet connection

Port Forwarding is required to be setup for *WAN Connection* via your hub or router




Check Communication

When the controller/s have been added to the software click **Operation**. Right click on the door icon and click **Check** to test the communication between the software and the access controller. You will see a similar image as below. Click on the **Clear Event Window** to clear the screen if required. Click **Adjust Time** followed by **Download** to ensure time synchronisation is correct between the computer and the access controller

Upload/Download – ! Important !

Operation/Console/Download

Ensure that you download any changes/edits made to users, door settings or any other setting to the controller. Whilst the changes will be stored within the software database, the controller will not respond to these changes unless you download them to it. To do this, click **Operation/Console/Download** Don't forget to highlight the door/s



Edit door names & Lock status


Configuration/Controllers/Edit

Edit the door names and control status of the doors

Control: Is normal PC control status

Open: Will keep the door open (Treat this facility with care)


Close: Will keep the door locked (Treat this facility with care)



Adding Departments/Branch/Users/Access Privilege

Configuration/Departments/Add Top

You can create departments and/or branches if required. Enter the name for the department/s and then click **OK**



Adding Personnel

Configuration/Personnel

There are four ways in which users can be added to the system, this can be undertaken individually, via a USB desktop reader, the door reader itself or manual batch input (**Manual batch input requires sequential card numbers**)

* **USB desktop card reader or door reader is recommended for adding several cards/fobs**


** You must issue all new card users **Access Privileges** before they can access any door/s

To manually enter a card, Click the **Add** button and insert the 8 digit Wiegand number printed on the right hand side of the card or the front of a key fob in to the **Card NO** box and a photo of the user if required

Click on **Auto Add** if using a USB desktop card reader or door reader to enter a card

Click **Others** to allow you to add extra information for the user if you wish

Click **OK** to exit or **Add Next** to add more users



AC8000 Access Control System

File Configuration Operation One Card Multifunction Tools Help

Getting Started
☒ Hide When Login

1. Add Controllers By
 2. Auto Add Cards By Swiping
 3. Add Privileges Allow And Download
 Swipe again, Open Hide

Configuration

Operation

Attendance

Controllers Department Personnel Access Privilege

Auto Add Add Edit Del Print Export To Excel Card Lost Batch Update Privilege Find

Name CardNO Dept. Query Clear

User ID	User Name	Card NO	Attendance	Access	Active Date	Deactive Date	Department
1	Andy	19533914	☒	☒	2014-06-06	2029-12-31	Installation
2	Kev	16029663	☒	☒	2014-06-07	2029-12-31	Sales
3	Dee	1232297	☒	☒	2014-06-07	2029-12-31	Admin
4	Dan	1232053	☒	☒	2014-06-07	2029-12-31	Sales
5	Sam	7435345	☒	☒	2014-06-07	2029-12-31	Admin
6	Mick	7423899	☒	☒	2014-06-07	2029-12-31	Installation

User

Main Others

*User ID: 1 * Required

*Name: Andy

Card NO: 19533914 Photo

Department: Installation

☒ Attendance ☒ Access Control

Activate: 2014-06-06

Deactivate: 2029-12-31

Des_Time 23:59

OK Exit


Access Privileges

Configuration/Personnel

In order to allow users through the door/s you need to allocate an **Access Privilege**

There are two ways to do this, individual users, multiple users and/or by departments

Highlight a user and click **Privilege**. Using the >> arrow button/s, select the door you wish the user to access and move it to the right hand side. Once complete, click **Confirm And Download**



AC8000 Access Control System

File Configuration Operation One Card Multifunction Tools Help

Controllers Department Personnel Access Privilege

Auto Add Add Edit Del Print Export To Excel Card Lost Batch Update Privilege Find

Name CardNO Dept. Query Clear

User ID	User Name	Card NO	Attendance	Access	Active Date	Deactive Date	Department
1	Andy	19633914	☒	☒	2014-06-06	2029-12-31	Installation
2	Kev	16029663	☒	☒	2014-06-07	2029-12-31	Sales
3	Dee	1232297	☒	☒	2014-06-07	2029-12-31	Admin
4	Dan	1232053	☒	☒	2014-06-07	2029-12-31	Sales
5	Sam	7436345	☒	☒	2014-06-07	2029-12-31	Admin
6	Mick	7423899	☒	☒	2014-06-07	2029-12-31	Installation

3.Deer - Privileges

Zone: (All Zones)

Optional Doors 0

Selected Doors 1

Office door

>> > < <<

Information

Are you sure update 3.Deer - Privileges (Doors Count = 1) ?


OK Cancel

Find Confirm Confirm And Download Cancel

Configuration/Personnel

To change the privileges of multiple users and/or by departments, click **Access Privilege/Change Privileges**

Using the >> arrow button/s, select the user/s or department and move them to the left hand side. Do the same for the door/s. Once complete, click **Allow And Download**




Lost User Card

Configuration/Personnel/Card Lost

It is very easy to locate and rectify a lost user card, navigate to the main software interface screen and click on

Configuration/Personnel/Card Lost

This screen will appear and you simply choose the card user or department for the lost card, issue and enter a new card number for the user and then click **OK**



Query Swipe Records

Operation / Query Swipe Records

Query Swipe Records will maintain **100,000 OFFLINE** transactions for all activity. You can filter this information by users, departments or date/time. This record cannot be deleted, however, it can be printed or exported to an Excel spread sheet

AC8000 Access Control System

File Configuration Operation One Card Multifunction Tools Help

Console Query Swipe Records

Print Export To Excel Query Options Find

From: <Event Time> 2014-06-07 Saturday To: <Event Time> 2014-06-07 Saturday Time: 00:00 To: 23:59

Name: CardNo: Dept:

Query Clear

RecID	Card No	User ID	User Name	Department	Admin	Installation	Sales	Valid	Description
1	0								door-Office door -In
2	85								Controller Power On
3	8								Forced Open
4	0								Door Open
5	85								Controller Reset-WDT
6	8								Forced Open
7	0								Door Open
8	85								Controller Reset-WDT
9	8								Forced Open
10	0								Door Open
11	85								Controller Reset-WDT
12	8								Forced Open
13	19533914	1	Andy	Installation	2014-06-06 17:44:15 Friday	Office door-Office door -Exit			Denied Access: Door Se...
14	19533914	1	Andy	Installation	2014-06-06 17:44:21 Friday	Office door-Office door -Exit			Denied Access: Door Se...
15	19533914	1	Andy	Installation	2014-06-06 17:46:05 Friday	Office door-Office door -Exit			Denied Access: Door Se...
16	19533914	1	Andy	Installation	2014-06-06 17:46:15 Friday	Office door-Office door -Exit			Denied Access: Door Se...
17	19533914	1	Andy	Installation	2014-06-06 17:49:15 Friday	Office door-Office door -Exit			Swipe
18	16029663	2	Kev	Sales	2014-06-07 13:27:16 Saturday	Office door-Office door -Exit			Swipe
19	19533914	1	Andy	Installation	2014-06-07 13:27:21 Saturday	Office door-Office door -In			Swipe
20	19533914	1	Andy	Installation	2014-06-07 13:27:21 Saturday	Office door-Office door -Exit			Swipe
21	7423899	6	Mick	Installation	2014-06-07 13:27:26 Saturday	Office door-Office door -Exit			Swipe
22	7435345	5	Sam	Admin	2014-06-07 13:27:31 Saturday	Office door-Office door -Exit			Swipe
23	1232053	4	Dan	Sales	2014-06-07 13:27:36 Saturday	Office door-Office door -Exit			Swipe
24	1232297	3	Dee	Admin	2014-06-07 13:27:41 Saturday	Office door-Office door -Exit			Swipe
25	16029663	2	Kev	Sales	2014-06-07 13:27:47 Saturday	Office door-Office door -In			Swipe
26	1232297	3	Dee	Admin	2014-06-07 13:27:51 Saturday	Office door-Office door -In			Swipe
27	1232297	3	Dee	Admin	2014-06-07 13:27:52 Saturday	Office door-Office door -Exit			Swipe
28	1232053	4	Dan	Sales	2014-06-07 13:27:57 Saturday	Office door-Office door -In			Swipe
29	7435345	5	Sam	Admin	2014-06-07 13:28:05 Saturday	Office door-Office door -In			Swipe
30	7423899	6	Mick	Installation	2014-06-07 13:28:10 Saturday	Office door-Office door -In			Swipe
31	19533914	1	Andy	Installation	2014-06-07 13:28:14 Saturday	Office door-Office door -In			Swipe

Configuration

Operation


Attendance

Monitoring

Operation/Console/Upload and Monitor

Highlight a door and click **Upload and Monitor**. This will allow you to monitor real time activity and also upload the very latest transactions to your computer that can be viewed by clicking **Query Swipe Records**

You can click on any user for individual information that will be displayed on the right side of the screen, however, if you want to find the exact location of each user or even who is presently inside or outside the building, right click the door and choose **Location or Persons Inside**




The screenshot shows the AC8000 Access Control System software. The sidebar on the left has three main sections: 'Configuration' (with a gear icon), 'Operation' (with a hand icon), and 'Attendance' (with a document icon). The 'Operation' section is active, showing a 'Console' tab and a 'Query Swipe Records' tab. The 'Console' tab is selected, displaying a list of doors. The 'Office door' is highlighted. Below the list, there is a table of swipe records. The table has columns for 'Time', 'Desc', and 'Info'. The records are as follows:

	Time	Desc	Info
✓ 1	15:52:16	Office door-Office door ...	16029663-Kev-Sales-2014-06-07 15:52:09 Saturday-Office door-Office door -In-Swipe
✓ 2	15:52:21	Office door-Office door ...	7435345-Sam-Admin-2014-06-07 15:52:17 Saturday-Office door-Office door -In-Swipe
✓ 3	15:52:26	Office door-Office door ...	1232053-Dan-Sales-2014-06-07 15:52:22 Saturday-Office door-Office door -In-Swipe

On the right side of the screen, there is a detailed view of the selected record (Card NO: 1232053). The details are as follows:

Card NO:	1232053
Name:	Dan
Dept:	Sales
Read Date:	2014-06-07 15:52:22 Saturday
Addr:	Office door-Office door -In
Status:	Swipe

The Location box will appear and you can filter this by either a user or department. Highlight a user and click **Query**. We know that Andy had entered the building and exited and also how long he stayed for



We know that Kev has not exited the building

AC8000 Access Control System

FileConfigurationOperationOne Card MultifunctionToolsHelp

Getting Started

Hide When Login

1. Add Controllers By

2. Auto Add Cards By Swiping

3. Add Privileges Allow And Download

Swipe again, Open

Hide

Configuration

Operation

Attendance

Console

Query Swipe Records

(All Zones)

Location

Department: (All)

User ID	User Name	Card NO
1	Andy	19533914
2	Kev	16029663
3	Dee	1232297
4	Dan	1232053
5	Sam	7435345
6	Mick	7423899

Release Machines And Monitor First

Query

Exit

Kev

2014-06-07 15:52:09 Saturday

Enter Into

Office door

Dont Go Off

Stay: 4 Minutes

	Time	Location	Card NO	Access
✓ 1	15:52:16	Office door-Office door ...	16029663-Kev-Sales-2014-06-07 15:52:09 Saturday-Office door-Office door -In-Swipe	
✓ 2	15:52:21	Office door-Office door ...	7435345-Sam-Admin-2014-06-07 15:52:17 Saturday-Office door-Office door -In-Swipe	
✓ 3	15:52:26	Office door-Office door ...	1232053-Dan-Sales-2014-06-07 15:52:22 Saturday-Office door-Office door -In-Swipe	

Name: Dan

Dept: Sales

Read Date: 2014-06-07 15:52:22 Saturday

Addr: Office door-Office door -In

Status: Swipe

Persons Inside

The Persons Inside box will appear box. You can **Auto Refresh Cycle** this and find out who is inside, who is outside or via a department. This shows three people inside

Getting Started

☒ Hide When Login

1. Add Controllers By

2. Auto Add Cards By Swiping

3. Add Privileges Allow And Download

Swipe again, Open Hide

Configuration

Operation

Attendance

FileConfigurationOperationOne Card MultifunctionToolsHelp

ConsoleQuery Swipe Records

Select AllStopCheckAdjust TimeUpload and Monitor...Clear Event WindowFind (All Zones)

Office door

Persons Inside [With Access Privilege]

PrintExport To Excel

Selected Zone: (All Zones)Query

Select AllSelect NonePlease Upload and Monitor First

☒ Office door

Query in the 1 DaysPersons Inside: 3Persons Outside: 3Auto Refresh Cycle: 5 Sec

Enter In DetailOutSideDepartment

User ID	User Name	Department	DateTime (In)	Addr
2	Kev	Sales	2014-06-07 15:52:09 Saturday	Office door
4	Dan	Sales	2014-06-07 15:52:22 Saturday	Office door
5	Sam	Admin	2014-06-07 15:52:17 Saturday	Office door

16632014-06-07 15:52:09 Saturday door-Office door-In

However, Dan has just exited the building which is displayed via the **Auto Refresh Cycle** of **Persons Inside** and **Persons Outside** which is transaction number 4 and also confirmed by the right hand screen in the back ground Click on **Outside** to double check

AC8000 Access Control System

File Configuration Operation One Card Multifunction Tools Help

Console Query Swipe Records

Select All Stop Check Adjust Time Upload and Monitor... Clear Event Window Find (All Zones)

Office door

Persons Inside [With Access Privilege]

Print Export To Excel

Selected Zone: (All Zones)

Select All Select None [Please Upload and Monitor First]

Query

Query in the 1 Day(s)

Persons Inside: 2

Persons Outside: 4

☒ Auto Refresh Cycle: 5 Sec

Enter in Detail Outside Department

	Time	Device
✓ 1	15:52:16	Office
✓ 2	15:52:21	Office
✓ 3	15:52:26	Office
✓ 4	16:03:49	Office

User ID	User Name	Department	DateTime (In)	Addr
2	Key	Sales	2014-06-07 15:52:09 Saturday	Office door
5	Sam	Admin	2014-06-07 15:52:17 Saturday	Office door

53 4

2014-06-07 16:03:45 Saturday
door-Office door -Exit

This confirms that Dan is now outside

AC8000 Access Control System

File Configuration Operation One Card Multifunction Tools Help

Getting Started
☒ Hide When Login
1. Add Controllers By
2. Auto Add Cards By Swiping
3. Add Privileges Allow And Download
Swipe again, Open
Hide

Configuration
Operation
Attendance

Console Query Swipe Records

Select All Stop Check Adjust Time Upload and Monitor... Clear Event Window Find (All Zones)

Office door

Persons Inside [With Access Privilege]

Print Export To Excel

Selected Zone: (All Zones) Query

Select All Select None (Please Upload and Monitor First)

Query in the 1 Day(s)
Persons Inside: 2
Persons Outside: 4

☒ Auto Refresh, Cycle: 5 Sec

Enter in Detail Outside Department

User ID	User Name	Department	DateTime (Out)	Addr
1	Andy	Installation	2014-06-07 15:42:33 Saturday	Office door
3	Dee	Admin	2014-06-07 15:42:28 Saturday	Office door
4	Dan	Sales	2014-06-07 16:03:45 Saturday	Office door
6	Mick	Installation	2014-06-07 15:03:06 Saturday	Office door

53 4


2014-06-07 16:03:45 Saturday
door-Office door -Exit

Backup Database & Restore

File/DB Backup

The software will auto backup the database when you exit the software, however, it is recommended to manually backup the database by clicking **File/DB Backup** and choose your required backup folder


This will be required in the event you need to re-install the software but do not wish to re-enter all the user data
You would simply copy and paste the database called **iCCard3000** from your backup folder in to the newly installed **AccessControl** folder









Extended Functions

Tools/Extended Functions (Password is **5678**)

The extended functions provide six sections offering a multitude of additional options to suit your own requirements as can be seen below. When you have chosen the options, you will be required to restart the software and the new options will be displayed. Under the main head sections will also display the shortcuts to the facility required **(Right click mouse)**







Time Profile

Configuration/Time Profile/New

Time Profile provides up to 255 time profile ID's with three timed segments which can be allocated to individual controllers, door readers, users, or departments. The example below shows how to link one profile to another. Enter the name of the profile in the **Description** box and choose an **Activate/Deactivate**, **Time Segment** and **Week Day** as required.

You will notice that our **Time Profile ID 2** is linked to **Linked Time Profile 3**. This is because users will also require access during the weekend.

The screenshot displays the AC8000 Access Control System software interface. The main window shows a table of Time Profiles. Profile 2 is selected, and its configuration is shown in the 'Time Profile' dialog box.

Time Profile ID	Mon	Tue	Wed	Thu	Fri	Sat	Sun	No. 1 Begin	End1	No. 2 Begin	End2	No. 3 Begin	End3	Linked Time Profile	Activate	Deactivate
2 [Week Days]	☒	☒	☒	☒	☒	☐	☐	08:00	17:00	00:00	00:00	00:00	00:00	3	2010-01-01	2029-12-31
3 [Weekends]	☐	☐	☐	☐	☐	☒	☒	16:00	21:00	00:00	00:00	00:00	00:00	0	2010-01-01	2029-12-31

The 'Time Profile' dialog box for Profile 2 shows the following configuration:

- Time Profile ID: 2
- Description: Week Days
- Linked Time Profile: 3
- Week Day: ☒ Monday, ☒ Tuesday, ☒ Wednesday, ☒ Thursday, ☒ Friday, ☐ Saturday, ☐ Sunday
- Time Segment:
 - No. 1: 08:00 - 17:00
 - No. 2: 00:00 - 00:00
 - No. 3: 00:00 - 00:00
- Limited Access Times:
 - ☒ Count By One Controller
 - ☐ Count By Each Reader
 - [D = No limit, Max = 31]
 - Current Month (Driver V5.30): 0
 - Current Day: 0
 - Segment NO. 1: 0
 - Segment NO. 2: 0
 - Segment NO. 3: 0

Note that you do not need to link **Time Profile ID 3**. When complete, click **Configuration/Access Privilege/Change Privileges** to allocate the timed profiles

The screenshot displays the AC8000 Access Control System software interface. The main window has a menu bar (File, Configuration, Operation, One Card Multifunction, Tools, Help) and a toolbar with buttons for Controllers, Building Room, Personnel, Access Privilege, Time Profile, Peripheral, Pwd MGT, Anti-passback, and Inter Lock. A left sidebar contains icons for Configuration, Operation, and Attendance. The main area shows a table of time profiles and a 'Time Profile' configuration dialog box.

Time Profile Table:


Time Profile ID	Mon	Tue	Wed	Thu	Fri	Sat	Sun	No.1 Begin	End1	No.2 Begin	End2	No.3 Begin	End3	Linked Time Profile	Activate	Deactivate
2 (Week Days)	☒	☒	☒	☒	☒	☐	☐	08:00	17:00	00:00	00:00	00:00	00:00	3	2010-01-01	2029-12-31
3 (Weekends)	☐	☐	☐	☐	☐	☒	☒	16:00	21:00	00:00	00:00	00:00	00:00	0	2010-01-01	2029-12-31

Time Profile Configuration Dialog:

- Time Profile ID: 3
- Description: Weekends
- Linked Time Profile: 0
- Activate: 2010-01-01
- Deactivate: 2029-12-31
- Week Day:
 - ☐ Monday
 - ☐ Tuesday
 - ☐ Wednesday
 - ☐ Thursday
 - ☐ Friday
 - ☒ Saturday
 - ☒ Sunday
- Time Segment:
 - No.1: 16:00 - 21:00
 - No.2: 00:00 - 00:00
 - No.3: 00:00 - 00:00
- Limited Access Times:
 - ☒ Count By One Controller
 - ☐ Count By Each Reader
 - [0 = No limit, Max = 31]
 - Current Month (Driver V5.30): 0
 - Current Day: 0
 - Segment NO.1: 0
 - Segment NO.2: 0
 - Segment NO.3: 0

Buttons: OK, Cancel

Using the >> arrow button/s, select the user/s or department and move them to the right hand side. Do the same for the door/s. Once complete, click **Allow And Download**



Fire Alarm Board (interface)

****Fire Regulations**


Please ensure you contact your local **Fire Officer** with regards to the inter-connection of access control equipment to your fire alarm system. More often than not, it will be acceptable to connect the fire alarm output to an independent auxiliary relay or double pole emergency break glass switch in order to deactivate the locking devices

The fire alarm panel manufacturer should always be contacted to ensure the auxiliary relays contained within the fire alarm panel, which will release the door, are of a suitable quality for life safety. Relays connected to any locking device must be energised in the non-alarm condition, i.e. the relay/s will be de-energised on alarm and will therefore tend to fail safe all devices connected

The AC-FAB (Fire Alarm Board interface) is an add-on module for the AC8000 PC Access Control System designed to accept a Normally Open contact input which then provides an alarm signal output via the software and/or activating any of the four timer relays provided in addition to ensuring the door/s are held in the unlocked state for as long as the alarm input is present (***Certain features of the AC-FAB will also require an RFID keypad and locking device fitted with door monitoring contacts***) It can also accept additional inputs to activate individual relays as and when required


It has a simple software interface that can be configured to your own requirements supporting one manual Normally Open trigger input from an alarm system or emergency break glass switch, four timer relay outputs from 0 – 6000 seconds (1.66hrs), all providing Normally Open and Normally Closed outputs that can be connected to external sounders, flashing beacons or any other device requiring a volt free contact input. Six triggering options are available that can be programmed to activate one or all four relays

It supports and registers via the software an emergency threat PIN code (***RFID Keypad is required for this***), if the door is open too long, door forced open, invalid card used, fire alarm and forced lock




Fire Alarm Board (interface)

158l x 43w x 15h



Example of the AC-FAB being activated by the alarm input, but also triggering one of the four relay outputs to activate a strobe light from 0 – 6000 seconds (1.66hrs)

The alarm input will keep the door/s unlocked until it has been reset (Providing the Normally Open input is not removed)




Peripheral

Configuration / Peripheral

The auxiliary relay board (Fire Alarm Board interface) has one manual Normally Open trigger input, two triggering sources (**Door or ARM ****) and four timer relay outputs from 0 – 6000 seconds (1.66hrs), providing Normally Open and Normally Closed outputs that can be connected to external sounders or flashing beacons etc. In addition to this, there are six triggering options that can be programmed to activate one or all four relays

The example below shows the standard (**Door**) configuration setup requiring the software to display when the door is open too long, if the door has been forced open, if an invalid card is being used to gain entry, if the alarm input has been activated and if a threat code has been used


In order to program the relay outputs, click **Hardware Configuration**. We have set relay output one to activate for 10 seconds



ARM **


The **Auxiliary Relay Method** option allows for additional inputs that can be used in conjunction with the standard **DOOR** configuration setup or independently to trigger the relay outputs (Non timed) and hold them open until the input has been reset, all of which can be configured by clicking the **OPTION** button

This example will trigger a Fire Alarm event via the software only and no relays will activate on the AC-FAB




This configuration will trigger a Fire Alarm event via the software and also activate relay output number 1 indefinitely on the AC-FAB until the trigger is reset

Please note that options EXTA1/2/3 do not function on the AC-FAB




This configuration will trigger a Fire Alarm event via the software, the door status (Open or closed) as well as the exit button being pressed and activate relay output number 2 indefinitely on the AC-FAB until the trigger is reset



Option Button

An additional three options are provided as to what the relay output does for the timed duration which can be set from 0 - 6000 seconds (1.66hrs) or if using the ARM option, there are five possible signal inputs available



Here you can see the relevant **'Trigger'** input is displayed via the software

This example shows that Sam has entered the building, the door opens, but it is open for too long. We close the door, however, an invalid card is then presented to the door, followed by a forced entry. We then close the door again. The fire alarm then activates followed by the threat code

The screenshot displays the AC8000 Access Control System software interface. The left sidebar contains icons for Configuration, Operation, and Attendance. The main window is titled 'Console' and 'Query Swipe Records'. It features a toolbar with buttons: Threat Code Click Confirm, Select All, Stop, Check, Adjust Time, Upload and Monitor, Remote Open, Clear Event Window, and Location. Below the toolbar, there is a section for 'Office door' with a green status indicator. The bottom of the interface shows a list of events with columns for Time, Desc, and Info. The events are as follows:

	Time	Desc	Info
✓ 1	14:33:16	Office door-Office do...	7435345-Sam-Admin-2014-06-15 14:33:09 Sunday-Office door-Office door -In-Swipe
! 2	14:33:18	Office door	2014-06-15 14:33:11 Sunday-Office door-Door Open
* 3	14:33:30	Office door	2014-06-15 14:33:23 Sunday-Office door-Open too long
! 4	14:33:44	Office door	2014-06-15 14:33:37 Sunday-Office door-Door Closed
! 5	14:34:03	Office door-Office do...	16144125-2014-06-15 14:33:56 Sunday-Office door-Office door -In-Denied Access:No PRIVILEGE
* 6	14:34:26	Office door	2014-06-15 14:34:19 Sunday-Office door-Forced Open
! 7	14:34:26	Office door	2014-06-15 14:34:19 Sunday-Office door-Door Open
! 8	14:34:44	Office door	2014-06-15 14:34:37 Sunday-Office door-Door Closed
* 9	14:34:58	Office door	2014-06-15 14:34:50 Sunday-Office door-Fire
* 10	14:35:16	Office door	2014-06-15 14:35:08 Sunday-Office door-Threat

On the right side of the event list, there is a 'Read Date' field showing '2014-06-15 10:14:35:08 Sunday' and a 'Status' field showing 'Office door Threat'.

Change Threat Code

A keypad is required for this and in the event of a threat or emergency access is required, the user would enter this number exactly without any prefix or suffix in order to gain entry. The threat code can be changed to any 6 digit number required

All users can enter this number. It cannot be 'Privileged' to individual users or departments, therefore, treat this function carefully and who you issue the code number to

A screenshot of a Windows-style dialog box titled "Change Threat Code". The dialog has a blue header bar with a yellow key icon on the left and a close button (X) on the right. The main area is light gray and contains two text input fields. The first field is labeled "New Password:" and the second is labeled "Confirm Password:". Below the fields are two buttons: "OK" and "Cancel".

Once you are happy with the settings, ensure you download to the controller. Click **Operation/Console/Download**. If you wish to monitor the results, click **Upload and Monitor**

Keypad Operation (PWD MGT)

Configuration/PWD MGT

A Wiegand keypad will provide more stringent access for all users and/or staff which can be used in four ways:


Card + PIN code

Card only

Wiegand PIN code

Master PIN code

Within the **Password Management** screen are four sub-sections, Card + PIN, PIN Code, Controller's Password and Manual Input Password. Tick each door required for keypad operation



PIN Code

The PIN Code screen will display all users or you can filter this to individual departments. The default PIN code for all users/departments is **345678** and displayed as **'UnChanged'**

Change PIN will of course allow you to enter a new 4-6 digit PIN code for each user and will be displayed as **'Changed'**. If you do not enter anything at all, it will display **'No Password'**

! Important !

Please ensure you make a note of all allocated PIN numbers for users. The software will not display the user PIN number at all

In the event that you have lost user PIN numbers, you can either manually change them or please contact your supplier who will give you full instructions as to what is required. It may take up to 24hrs to provide your original user PIN numbers and a charge may be incurred for this service

With the configurations we have set in the below example (**Changed/UnChanged & No Password**) will be as follows:

- 1) Andy & Kev must present their **'Card + PIN + #'** in order to gain access
- 2) Dee & Dan must present their **'Card + (Default PIN 345678)'** in order to gain access (# is not required)
- 3) Sam, Mick & Dave can present their **'Card'** or enter **'* + the 8 digit Wiegand number on their card + #'** in order to gain access

The screenshot shows a software window titled "Password Management". It has four tabs: "Card + PIN", "PIN Code", "Controller's Password", and "Manual Input Password". The "Card + PIN" tab is selected. Below the tabs is a dropdown menu labeled "Building Room:" with "(All)" selected. Below this is a table with the following data:


User ID	User Name	Card NO	Building Room	PIN
1	Andy	19533914	Installation	Changed
2	Kev	16029663	Sales	Changed
3	Dee	1232297	Admin	UnChanged
4	Dan	1232053	Sales	UnChanged
5	Sam	7435345	Admin	No Password
6	Mick	7423899	Installation	No Password
7	Dave	16335339		No Password

Below the table is a large empty rectangular area. At the bottom of the window, there are three buttons: "Change PIN", "OK", and "Cancel".

Controller's Password

Master PIN codes can also be created for senior staff up to a maximum of 4 PIN codes per door – Users and Master PIN codes can be 4-6 digits

Enter '**PIN + #**' in order to gain access



The 'Password Management' window has four tabs: 'Card + PIN', 'PIN Code', 'Controller's Password' (selected), and 'Manual Input Password'. The 'Controller's Password' tab contains a table with two columns: 'Super' and 'Adapted Reader'. The table lists four entries: 1234 (A11), 3456 (A11), 4524 (A11), and 9250 (A11). To the right of the table is a form with a 'Show Password' checkbox (checked), a 'New Password' text field, and an 'Adapt To' dropdown menu set to '(All)'. Below the form is a note: 'Note: Maximum number of Super PIN codes must not exceed four per door'. At the bottom of the form are 'Add' and 'Delete' buttons. The window has 'OK' and 'Cancel' buttons at the bottom right.

Super	Adapted Reader
1234	(A11)
3456	(A11)
4524	(A11)
9250	(A11)

☒ Show Password

New Password:

Adapt To:

Note:
Maximum number of Super PIN codes
must not exceed four per door

Manual Input Password

Users who have a **'No Password'** can present their **'Card'** or **'* + the 8 digit Wiegand number on their card + #'** in order to gain access

Password Management

Card + PIN

PIN Code

Controller's Password

Manual Input Password

Reader #	SN	Description	Position	Manual Input
1	123103413	1	Office door-Office door -In	☒
2	123103413	2	Office door-Office door -Exit	☒


OK

Cancel

Anti-Passback

Configuration / Anti-Passback

Anti-passback is a secure feature requiring a card reader for entry and exit in order for it to function correctly. This facility prevents a card or PIN code from being used twice to gain access through a door without it being used to exit a door. This prevents users who gain access, then **"Passback"** their card to another user to gain entry at a later time. An ideal feature for health clubs, gyms or social clubs who may charge an annual fee for membership




Interlock

Configuration / Inter Lock

You can create an inter lock facility whereby one door is open and the second door is closed. The second door will not open until the first door is closed (You will require standard **door contacts** for this or a monitored magnetic lock or monitored lock release fitted with monitoring door contacts)

(Not available on single door controllers)

Door Contacts: Door contacts connected to the control board will inform the software as to the actual status of the door in question, in this way, the software can detect if the door is in a physical open or closed state, regardless if the locking device is actually locked or unlocked




Task List

Configuration/Task List

This option is for setting times of the day and/or days of the week where you require to control the door status automatically, for example, a School may require the door/s to open first thing in the morning or perhaps a Hospital requires absolute no access for door/s of a night time

Click on the **Task** drop down menu button to display a variety of available options which can be adapted to individual or all doors

A maximum of 64 settings can be made and can be edited at anytime



This example shows all doors will open at 07.00am and then reverting to door controlled status at 07.30am for one day only

Choose an activation and deactivation date, an activation time, day of the week, which door the task should be adapted to and finally choose a task. When complete, click **Add**

Controller Task List

Activate Date:

2014-06-20 Friday

Deactivate Date:

2014-06-20 Friday

Activation Time:

07:30

Week Day

☐ Monday
 ☐ Tuesday
 ☐ Wednesday
 ☐ Thursday
 ☒ Friday
 ☐ Saturday
 ☐ Sunday

Adapt To:

(All)

Task:

0. Door Controlled

Note:

Add

Delete

Edit

Close

TaskID	From	To	Time	Mon	Tue	Wed	Thu	Fri	Sat	Sun	Adapt To	Task	Note
1	2014-06-20 Friday	2014-06-20 Friday	07:00	☐	☐	☐	☐	☒	☐	☐	(All)	1. Door Open	
2	2014-06-20 Friday	2014-06-20 Friday	07:30	☐	☐	☐	☐	☒	☐	☐	(All)	0. Door Controlled	

Attendance/Manual Sign In

Attendance (Time Attendance) literally operates in the background for all users and departments and allows you to create daily and annual leave, work shift hours and manual sign in for individual users and/or departments for specific days and time. Complex, simplified or filtered reports can be printed directly to your printer or exported to Excel

Please ensure: User privileges are set for Attendance

Manual Sign In will provide an **ON DUTY** time for users or departments within the reports. This will only be required if you have temporary staff for example, if not, then you do not need to enter any details

Click the **+Add** button to create a new **Manual Sign In**, select the users or departments on the left and then using the **>>** arrow button/s, move them to the right. When complete, click **Add** followed by **Close**

The screenshot shows the 'Manual Sign In' window in the AC8000 Access Control System. The window has a menu bar with 'File', 'Configuration', 'Operation', 'One Card Multifunction', 'Tools', and 'Help'. Below the menu bar are tabs for 'Attendance Report', 'Normal Shift Rules', 'Holiday', 'Leave/Business Trip', and 'Manual Sign'. The 'Manual Sign' tab is active. On the left side of the window, there is a sidebar with icons for 'Configuration', 'Operation', 'Attendance', and 'Const Meal'. The main area of the window contains a form for entering sign-in details. At the top, there are fields for 'From' (2014-01-01 Wednesday) and 'To' (2014-12-31 Wednesday). Below these are fields for 'Name' and 'Dept.'. A table with columns 'RecID', 'Building', 'User ID', 'User Name', 'Date, Time (Manual)', and 'Note' is visible. In the center, there is a 'Manual Sign In' sub-window. It has a 'Time' field set to '2014-11-30 Sunday 15:20'. Below this is a 'Note' field. There are two tables: 'Users' and 'Selected Users'. The 'Users' table has columns 'User ID', 'User Name', and 'Card NO'. It lists users 2 (Rev), 3 (Dee), 5 (Sam), 6 (Mick), 7 (N9537432), 8 (N16144125), and 9 (Master Code). The 'Selected Users' table has the same columns and lists user 4 (Dan). Between the two tables are buttons '>>', '>', '<', and '<<'. A red arrow points from the 'Add' button in the top left of the 'Manual Sign In' sub-window to the '>>' button.

User ID	User Name	Card NO
2	Rev	16029663
3	Dee	1232297
5	Sam	7435345
6	Mick	7423899
7	N9537432	9537432
8	N16144125	16144125
9	Master Code	9250

User ID	User Name	Card NO
4	Dan	1232053

Leave/Business Trip

This will allow you to allocate business, sickness and private leave for users and/or departments

You can also create your own title by clicking on **Type Setup**

Click the **+Add** button to create a new "Leave", select the users or departments on the left and then using the **>>** arrow button/s, move them to the right. When complete, click **Add** followed by **Close**

The screenshot shows the AC8000 Access Control System interface. The 'Leave / Business Trip Compensation Sign In' window is open, displaying a list of users on the left and a 'Selected Users' table on the right. The 'Type Setup' button is circled in red. A red double-headed arrow points between the 'Users' and 'Selected Users' tables.

Users Table:

User ID	User Name	Card NO
3	Dee	1232297
5	Sam	7435345
6	Mick	7423899
7	NB537432	9537432
8	N16144125	16144125
9	Master Code	9250


Selected Users Table:

User ID	User Name	Card NO
2	Kev	16029663
4	Dan	1232053

Type Setup

Create your own "Leave" title by clicking **Type Setup/Add/New Name**


When complete, click **OK**



This will allow you to allocate Company leave such as Easter, Christmas, New Year, Bank Holidays or whatever you choose. This will be displayed on the reports as a * for each user/department

Normal Shift Rules

This will allow you to allocate normal working hour start and finish times as well as an amount of time from 1 – 600 minutes for arriving late or leaving early. It also provides an advanced facility if required. Correctly setting these options will generate a more enhanced **Attendance Report** such as time arrived, time arrived late, time left and time left late




Attendance Report

Click **Create** to generate a report – up to date reports will require you to **Upload** the latest transactions in the first instance. Click **Operation/Console/Upload**

The attendance report can be filtered by user or department for all or selected dates. Note that our user Dan is required for manual sign in, this report shows he is required to sign in at 15.20pm, however, his sign in time was 15.36pm and he left early at 15.49pm by 31 minutes

Right clicking on the report will allow you to select particular configure columns for preferred viewing which can be saved

Query Option will allow you to view specific results of the report. The report can be printed directly to your printer or exported to Excel



Columns dialog box showing a list of columns to select. The 'Create' button is circled in red.

Select columns to show.

- ☐ Building Room
- ☐ User ID
- ☒ User Name
- ☒ Date
- ☐ Shift ID
- ☐ Times
- ☒ A.M. OnDuty
- ☒ On Desc
- ☒ P.M. OffDuty
- ☒ Off Desc
- ☐ OnDuty2
- ☐ On2 Desc
- ☐ OffDuty2
- ☐ Off2 Desc
- ☐ OnDuty3

OK Cancel




Query Option dialog box showing options for the report. The 'Absent' checkbox is checked.

Query Option

- ☐ Arrive late
- ☐ LeaveEarly
- ☒ Absent
- ☐ Manual Sign
- ☐ Not Swipe
- ☐ Overtime

Query Close



AC8000 Access Control System main window showing the Attendance Report. The 'Create' button is circled in red. The report shows a table of attendance data for 2014-11-30 Sunday.

Building Room	User ID	User Name	Date	A.M. OnDuty	On Desc	P.M. OffDuty	Off Desc	Late min	Leave min	Overtime (hr)	Absence Days	Not Swipe
Sales	2	Kev	2014-11-30 Sunday		Absent		Absent					
Admin	3	Dee	2014-11-30 Sunday		Absent		Absent					
Sales	4	Dan	2014-11-30 Sunday	15:36:01	Arrive late	15:49:00	LeaveEarly	16	31			
Admin	5	Sam	2014-11-30 Sunday		Absent		Absent					
Installation	6	Mick	2014-11-30 Sunday	15:45:19	Arrive late		Not Swipe	25				1
	7	N9537432	2014-11-30 Sunday		Absent		Absent					
Installation	8	N16144125	2014-11-30 Sunday		Absent		Absent					
	9	Master Code	2014-11-30 Sunday		Absent		Absent					

Statistics

The statistics button will provide an individual report for days worked, lateness, early leave, sick leave, annual leave and so on. This can also be printed or exported to Excel

Attendance Statistics

Print
Export To Excel
Find
Close

Name
Dept.
Query
Clear

Creating Attendance Report Log: [Operating Date: 2014-12-03 15:26:36 Wednesday]; From 2014-11-30 To 2014-12-03; Building Room:
User (8)


	Building Room	User ID	User Name	Planned Days	Full Work Days	Late Minutes	Late Count	Leave Early Minute	Leave Early Count	Over (hr)	Absent Days	Not Swiped	Manual Sign In (Times)	Business Trip (Days)	Sick Leave (Days)	Private Leave (Days)
	Sales	2	Kev	4		10	1					1	1			
	Admin	3	Dee	4		10	1					1	1			
	Sales	4	Dan	4		10	1					1	1			
	Admin	5	Sam	4		10	1					1	1			
	Installation	6	Mick	4		10	1					1	1			
		7	N9537432	4		10	1					1	1			
	Installation	8	N16144125	4		10	1					1	1			
		9	Master Code	4		10	1					1	1			

Const Meal

The Meal Setup is primarily designed for charging entry and/or exit to an on-site or factory canteen to enable a cost charge per user or department. The facility could be also used for any other requirement needing to make a charge for entry and/or exit

You can allocate a fixed rate for entry or exit or even allocate a higher rate for individual door readers for special occasions or “One off events” in addition to charging different amounts for certain times of the day

Click **Meal Setup** to begin



In the Meal Setup, you have three sections, Readers, Rules and Meal Period



Readers

Choose the door/s on the left and then using the >> arrow button/s, move them to the right. When complete, click **OK**. Readers chosen will of course be chargeable when accessed

Rules

There are three options

- 1) One swipe counts as one meal (Or entry)
- 2) More swipes within the same **Meal Period** as ONLY one meal (Or entry)
- 3) More swipes as one meal if the interval between them is less than the allocated time (With the Meal Period - Default is 60 seconds)




Meal Period

There are four timed options available for morning, lunch, evening and other. This is where you choose the amount to charge for entry and/or exit


Option

Choosing this option allows you to make an overridden cost for the selected door reader for either one or all of the four timed options available

Choose the door/s on the left and then using the >> arrow button/s, move them to the right. When complete, click **OK**



The Meal Setup dialog box has three tabs: Readers, Rules, and Meal Period. The Meal Period tab is active. It contains a section for Time Segments with four options: Morning, Lunch, Evening, and Other. The Morning option is selected. Below this, there is a section for Department Method with a dropdown menu set to 'According To Group'. To the right of the Time Segments, there is a field for 'US\$ / One Swipe' set to 11.00. An 'Option' button is circled in red. At the bottom are 'OK' and 'Cancel' buttons.




The Meal Option-Morning dialog box shows two lists of readers. The left list is 'Readers for Meal' and the right list is 'Readers for Special Cost'. A red double-headed arrow indicates the movement of readers between these two lists. The 'Readers for Special Cost' list contains one entry: Reader ID 1, Name 'Office door...', and US\$ / Swipe 5.00. Between the lists are four arrow buttons: >>, >, <, and <<. At the bottom are 'OK' and 'Cancel' buttons.


Department Method (According To Group)

Using the According To Group option allows you to make a single cost charge per department. Double click on the **'Enable'** button to display an additional box allowing you to enter the desired amount to charge or disable the department

When complete, click **OK**



The Meal Group Configure dialog box shows a table with columns: Building Room, Enable, Morning, Lunch, Evening, and Other. The table lists three groups: Admin, Installation, and Sales. The 'Enable' column has checkboxes for each group. The 'Morning' column has values: 100.00 for Admin, 100.00 for Installation, and 0.00 for Sales. The 'Lunch', 'Evening', and 'Other' columns all have values of 0.00. At the bottom are 'OK' and 'Cancel' buttons.



The Meal Unit Set dialog box shows a section for 'US\$ / One Swipe' with four input fields: Morning (100.00), Lunch (0.00), Evening (0.00), and Other (0.00). Below these fields is a checkbox labeled 'Enable' which is checked. At the bottom are 'OK' and 'Cancel' buttons.

Meal Reports

Click **Create** to generate a report – up to date reports will require you to **Upload** the latest transactions in the first instance. Click **Operation/Console/Upload**

The meal report can be filtered by user or department for all or selected dates and can be printed directly to your printer or exported to Excel

Examples: (1-3)

This example shows Mick entering twice (The default time for this particular example was 5 seconds) which has incurred £2

The screenshot shows the 'Meal' application window. The menu bar includes 'Meal Setup', 'Create', 'Print', 'Export To Excel', 'Find', and 'Close'. The date range is set to 'From: 2014-12-04 Thursday' to 'To: 2014-12-04 Thursday'. The 'Name' field is empty, and the 'Dept.' dropdown is open, showing 'Admin', 'Installation', and 'Sales'. The 'Detail' tab is selected, showing a table with columns: RecID, Building Room, User ID, User Name, DateTime, Meal Name, Cost (US\$), and Addr. Two entries are visible:

RecID	Building Room	User ID	User Name	DateTime	Meal Name	Cost (US\$)	Addr
799	Installation	6	Mick	2014-12-04 15:22:48 Thursday	Morning	1.00	Office door-Office door-In
801	Installation	6	Mick	2014-12-04 15:23:13 Thursday	Morning	1.00	Office door-Office door-In

2) This example shows Mick entering twice (We have used the **Option** box to make an overridden cost for the selected door reader) which has incurred £10

The screenshot shows the 'Meal' application window. The menu bar is the same. The date range is set to 'From: 2014-12-04 Thursday' to 'To: 2014-12-05 Friday'. The 'Name' field is set to '6-Mick-7423899'. The 'Dept.' dropdown is open, showing 'Admin', 'Installation', and 'Sales'. The 'Detail' tab is selected, showing a table with columns: RecID, Building Room, User ID, User Name, DateTime, Meal Name, Cost (US\$), and Addr. Two entries are visible:

RecID	Building Room	User ID	User Name	DateTime	Meal Name	Cost (US\$)	Addr
799	Installation	6	Mick	2014-12-04 15:22:48 Thursday	Morning	5.00	Office door-Office door-In
801	Installation	6	Mick	2014-12-04 15:23:13 Thursday	Morning	5.00	Office door-Office door-In

3) This example shows Mick entering twice (We have the option of **Department Method** (According To Group) to make an overridden cost for the selected door reader) which has incurred £200

Meal

Meal Setup

Create

Print

Export To Excel

Find

Close

From: 2014-12-04 Thursday

To: 2014-12-05 Friday

Name 6-Mick-7423899

Dept.

Clear

Detail

Subtotal of Readers

Subtotal of Bulding Room


Statistics(2014-12-04 To 2014-12-05)

RecID	Bulding Room	User ID	User Name	DateTime	Meal Name	Cost (US\$)	Addr
799	Installation	6	Mick	2014-12-04 15:22:48 Thursday	Morning	100.00	Office door-Office door -In
801	Installation	6	Mick	2014-12-04 15:23:13 Thursday	Morning	100.00	Office door-Office door -In


SQL Server Configuration

Install the SQL Server, and then configure Access Control SQL Server


Click 【Start】 > 【Programs】 > 【AccessControl】 > 【SqlSet】




Click “Create Database”



Click “OK”



Click “OK”, Then Click “Confirm”



Click “OK”, Run Software “Access Control”, You can see the created database icon as “SQL:AccessData”.

