Basic System Layout

Important:

1) Please observe the colour code on the rear of the door panel

L1 L2 PL S1+ S2+ S1-

DPS

PS4

Door Panel   Monitor

−

+

AC-220-240v

ON

1 2 3 4 5 6

Code=0, DIP 6 = on