

Connecting to Gate Controller

Important:

- 1) Remove the black jumper link from the front of the door panel
- 2) Please observe the colour code on the rear of the door panel
- 3) Connection wire "PL" below is WHITE

