

Connecting to a Keypad

Important:

- 1) Ensure the magnetic lock is set for 24v dc operation
- 2) Remove the black jumper link from the front of the door panel
- 3) Please observe the colour code on the rear of the door panel
- 4) Connection wire "PL" below is WHITE

