




Basic System Layout




Remove jumper link from rear of door panel if connecting to a gate controller



Single Door Panel With Multi Monitors



Single Door Panel With Multi Monitors Using DBC4S




Remove jumper link from rear of door panel if connecting to a gate controller


To gate controller

BUS line to DPS

Multi Door Panel With Multi Monitors



Multi Door Panel With Multi Monitors using DBC4S



Connecting to Magnetic Lock - All Systems

Important:

- 1) The PS5 power supply & TR1 relay is required for all installations using a magnetic lock
- 2) Ensure the magnetic lock is set for 24v dc operation
- 3) Remove the black jumper link from the rear of the relevant door panel

